

# SUREBOND

CEMENTITIOUS BOND COAT



**SURECRETE**  
DESIGN PRODUCTS

Toll Free 1-800-544-8488  
Local 1-352-567-7973  
[www.SureCreteDesign.com](http://www.SureCreteDesign.com)

## Technical Data

### COVERAGE

50 pounds will cover between 300 –450 sq. ft. based upon porosity of slab.

### LIMITATIONS

**SureBond** must be applied in temperatures above 40°F and remain above 40°F for 24 hrs. Do not allow **SureBond** to freeze for 48 hrs. after placement.

### DESCRIPTION

**SureBond** is a single component, just add water, cement based bonding agent specifically developed for SureCrete's patching products and **SureStamp** stamped overlayment. Its only function is to join these products to the host surface (i.e. concrete.) **SureBond** is composed of a high concentration of latex modifier and cement with a very fine sand for aggregate.

### SURFACE PREPARATION

Remove all laitance, efflorescence, chemical contaminants, grease, oil, old paint, and other foreign matter. The prepared surface must be clean and structurally sound. The surface may require profiling. Sand blasting, grinding or shot blasting may be necessary to get to bare concrete. Substrate must be 40°F and rising before installation. Surface at 90°F and above must be cooled before installation. Dampen area with fog tipped sprayer before using, leaving no puddles.

### APPLICATION

#### **For Patching**

Mix only the amount of **SureBond** that may required to coat the area to patch. Water demand can be determined by site; mix a little bit thicker than a slurry. Unless patched area is overly large, apply **SureBond** with a chip brush. Be certain to coat complete area to patch, including adjacent areas if patching material is to "feather" to zero at edges. Apply patching material while **SureBond** is still wet.

#### **For SureStamp**

Unless area to be stamp overlayed is very small, mix Bond Coat at the rate of 7 – 7 ½ qts. water to a 50 lb. bag of **SureBond**. Mechanically mix to a lump-free consistency. Begin by saturating area to be covered with water. Before application of bond coat, remove any excess water leaving no puddles. The surface should be saturated, surface dry (SSD). Place the bond coat with a squeegee and force into surface completely covering existing concrete with this slurry. Apply **SureBond** only in sections that may be covered with stamp mix while maintaining a wet edge.

### WARRANTY

Warranty of this product, when used according to the directions, is limited to refund of purchase price, or replacement of product (if defective), at manufactures/seller's option. SureCrete Design Products shall not be liable for cost of labor or direct and/or incidental consequential damages.

### CLEAN UP

Clean up is simple and easy with soap and water. Rinse tools before material hardens.

